



HT32F1656 Starter Kit User Manual

Revision: V1.00 Date: July 17, 2015

[**www.holtek.com**](http://www.holtek.com)

Table of Contents

1 Introduction.....	5
Features.....	6
2 Hardware Layout.....	7
Boot Option.....	9
V _{BAT} Option – JP9.....	9
LED Option – JP2, JP11	10
High Speed External Crystal Oscillator (HSE) Option – JP1, JP5.....	11
Low Speed External Crystal Oscillator (LSE) Option – JP3, JP4	11
SWD-10P Connector – JP26	12
Adjustment SWD-10P Connector (for e-Link32 Lite) – JP27	13
Extension connector 1 – J31	14
Extension connector 2 – J32	15
Mini USB type B Connector – U3	16
3 Schematics.....	17

List of Figures

Figure 1. HT32F1656 Starter Kit.....	5
Figure 2. HT32F1656 Starter Kit Block Diagram	7
Figure 3. HT32F1656 Starter Kit Layout.....	8
Figure 4. SWD-10P Connector	12
Figure 5. Adjustment SWD-10P Connector	13
Figure 6. Extension Connector 1	14
Figure 7. Extension Connector 2	15
Figure 8. Mini USB type B Connector.....	16
Figure 9. MCU, Boot Pins and Extension Connector.....	18
Figure 10. SWD Connector, LED Display and the Power.....	19
Figure 11. e-Link32 Lite	20

List of Tables

Table 1. Boot Jumpers	9
Table 2. V _{BAT} Jumpers	9
Table 3. LED1 Jumpers	10
Table 4. LED2 Jumpers	10
Table 5. HSE Jumpers	11
Table 6. LSE Jumpers.....	11
Table 7. SWD-10P Connector.....	12
Table 8. Adjustment SWD-10P Connector.....	13
Table 9. Extension Connector 1	14
Table 10. Extension Connector 2.....	15
Table 11. Mini USB type B Connector.....	16

1 Introduction

The HT32F1656 Starter Kit is based around the 32-bit ARM Cortex™-M3 high performance microcontroller and is designed to assist users to get up and running with this device as quickly as possible. It provides a complete solution from evaluation, programming to production.

The Starter Kit is based on the Cortex™-M3 high speed microcontroller, the operating frequency is up to 72MHz. It provides 256 KB of embedded Flash memory, 32 KB of embedded SRAM memory, multiple Timers, dual I²C interfaces, dual SPI interfaces, dual USART interfaces, dual UART interfaces, I²S, EBI, CRC-16/32, 12-bit A/D converter, 80 programmable general purpose I/O pins and a USB function which can be used to interface to a wide range of external devices.

This development platform is composed of a Target Board and Serial-Wire Debugger (e-Link32 Lite) and as such requires no external debugging equipment. It can use the Target Board external power supply or be powered by the Debugger.

The Starter Kit provides a standard C language program development environment for Keil μVision and IAR EWARM. With this basis, Holtek also provides a complete function library to avoid complicated lower level function development in order to allow development designers to focus on the needs of their application development. Using a simple USB cable connection, users only have to connect their PC to the integrated hardware debug interface (Serial-Wire Debugger), to automatically download the programs and immediately commence debug operations.




Figure 1. HT32F1656 Starter Kit

Features

- Using HT32F1656 high performance microcontroller
 - Up to 72 MHz operating frequency
 - 256 KB Flash, 32 KB SRAM
 - Integrated multiple Timers, dual I²C functions, dual SPI functions, dual USART functions, dual UART functions, single 12-bit A/D converter, USB and I²S function
 - LQFP100 package
 - 8 MHz external crystal clock
 - 80 programmable general purpose I/O pins
- Comprises Target Board and Serial-Wire Debugger
- Can be used for the testing and development of many external devices
- Can use the Target Board external power supply or be powered by the Debugger

2 Hardware Layout




Figure 2. HT32F1656 Starter Kit Block Diagram







Figure 3. HT32F1656 Starter Kit Layout



Boot Option

Table 1. Boot Jumpers

Jumper	Description
A8 & A9	<p>Boot loader mode</p>  <p>Boot from the embedded boot loader.</p>
	<p>SRAM mode</p>  <p>Boot from the embedded SRAM.</p>
	<p>Main flash mode – default setting</p>  <p>Boot from the embedded main flash. BOOT0 (A8) don't care and BOOT1 (A9) = 1</p>

V_{BAT} Option – JP9

Table 2. V_{BAT} Jumpers

Jumper	Description
VBAT	<p>V_{BAT} pin is connected to 3.3V power - default setting</p> 
	<p>V_{BAT} pin is connected to 3V CR1220 battery.</p> 

LED Option – JP2, JP11

Table 3. LED1 Jumpers







Jumper	Description
C9	LED1 connected with the extension I/O header and I/O port C pin 9 (C9) – default setting 
	C9 can only connect to extension I/O header. 

Table 4. LED2 Jumpers

Jumper	Description
C11	LED2 connected with the extension I/O header and I/O port C pin 11 (C11) – default setting 
	C11 can only connect to extension I/O header. 



High Speed External Crystal Oscillator (HSE) Option – JP1, JP5

Table 5. HSE Jumpers

Jumper	Description
B14 & B15	<p>HSE mode – default setting</p> 
	<p>I/O mode of I/O port B pin 14 (B14) and I/O port B pin 15 (B15).</p> 

Low Speed External Crystal Oscillator (LSE) Option – JP3, JP4

Table 6. LSE Jumpers

Jumper	Description
C13 & C14	<p>LSE mode – default setting</p> 
	<p>I/O mode of I/O port C pin 13 (C13) and I/O port C pin 14 (C14).</p> 

SWD-10P Connector – JP26




Figure 4. SWD-10P Connector

Table 7. SWD-10P Connector

Pin#	Description	Pin#	Description
1	3.3V	2	SWDIO (PA13)
3	GND	4	SWCLK (PA12)
5	GND	6	TRACESWO (PA11)
7	5V	8	NC
9	GND	10	Reset#

Adjustment SWD-10P Connector (for e-Link32 Lite) – JP27




Figure 5. Adjustment SWD-10P Connector

Table 8. Adjustment SWD-10P Connector

Pin#	Description	Pin#	Description
1	3.3V	2	SWDIO (PA13)
3	GND	4	SWCLK (PA12)
5	GND	6	TRACESWO (PA11)
7	5V	8	NC
9	GND	10	Reset#

Extension connector 1 – J31




Figure 6. Extension Connector 1

Table 9. Extension Connector 1

Pin#	Description	Pin#	Description
1	A0	2	A1
3	A2	4	A3
5	A4	6	A5
7	A6	8	A7
9	E8	10	E9
11	E10	12	E11
13	E12	14	C9 (LED1 Option)
15	C10	16	C11 (LED2 Option)
17	C12	18	D6
19	B12	20	B13
21	C13 (LSE Option)	22	C14 (LSE Option)
23	C15	24	D0
25	E13	26	E14
27	E15	28	B14 (HSE Option)
29	B15 (HSE Option)	30	D1
31	D2	32	D3
33	D4	34	D5
35	C0	36	C1
37	C2	38	C3
39	D7	40	D8
41	Reset#	42	VBAT (V _{BAT} Option)
43	3.3V	44	3.3V
45	3.3V	46	3.3V
47	GND	48	GND
49	GND	50	GND
51	NC	52	NC
53	NC	54	NC

Extension connector 2 – J32




Figure 7. Extension Connector 2

Table 10. Extension Connector 2

Pin#	Description	Pin#	Description
1	B10	2	B11
3	B8	4	B9
5	B6	6	B7
7	E6	8	E7
9	E4	10	E5
11	E2	12	E3
13	C8	14	E1
15	B5	16	C7
17	B3	18	B4
19	E0	20	B2
21	D14	22	D15
23	D12	24	D13
25	D10	26	D11
27	C6	28	D9
29	C4	30	C5
31	B0	32	B1
33	A14	34	A15
35	A12 (SWCLK)	36	A13 (SWDIO)
37	A10	38	A11 (TRACESWO)
39	A8 (Boot Option)	40	A9 (Boot Option)
41	3.3V	42	3.3V
43	3.3V	44	3.3V
45	GND	46	GND
47	GND	48	GND
49	GND	50	GND
51	5V	52	5V
53	5V	54	5V

Mini USB type B Connector – U3




Figure 8. Mini USB type B Connector

Table 11. Mini USB type B Connector

Pin#	Description	Pin#	Description
1	USB_5V	2	D-
3	D+	4	NC
5	GND		

3 Schematics

This section shows the complete circuit of the HT32F1656 Starter kit:

- Figure 9. Includes the MCU, Boot Pins and Extension Connector.
- Figure 10. Includes SWD Connector, LED Display and the Power.
- Figure 11. Includes the e-Link32 Lite.




Figure 10. SWD Connector, LED Display and the Power




Figure 11. e-Link32 Lite

Copyright© 2015 by HOLTEK SEMICONDUCTOR INC.

The information appearing in this Data Sheet is believed to be accurate at the time of publication. However, Holtek assumes no responsibility arising from the use of the specifications described. The applications mentioned herein are used solely for the purpose of illustration and Holtek makes no warranty or representation that such applications will be suitable without further modification, nor recommends the use of its products for application that may present a risk to human life due to malfunction or otherwise. Holtek's products are not authorized for use as critical components in life support devices or systems. Holtek reserves the right to alter its products without prior notification. For the most up-to-date information, please visit our web site at <http://www.holtek.com.tw>.